

User Manual
Instrukcja Obsługi



MOVING HEAD LED 150W SPOT

F7100501

1. INTRODUCTION

THANK YOU FOR PURCHASING **LED MOVING HEAD 150W SPOT**. FOR SAFETY REASONS AND TO ENSURE THE TROUBLE-FREE OPERATION, CAREFULLY READ THE INSTRUCTIONS.

2. SAFETY INFORMATION

■ Please keep this User Manual for future consultation. If you sell the fixture to another user, be sure that they also receive this instruction booklet.

■ Unpack and check carefully there is no transportation damage before using the fixture.

■ Before operating, ensure that the voltage and frequency of power supply match the power requirements of the fixture.

■ It's important to ground the yellow/green conductor to earth in order to avoid electric shock.

■ Disconnect main power before servicing and maintenance.

■ Use safety chain when fixes this fixture. Don't handle the fixture by taking its head only, but always by taking its base.

■ Maximum ambient temperature is: 40°C

Don't operate it where the temperature is higher than this.

■ In the event of serious operating problem, stop using the fixture immediately. Never try to repair the fixture by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.

■ Do not connect the device to any dimmer pack.

■ Do not touch any wire during operation and there might be a hazard of electric shock.

■ To prevent or reduce the risk of electrical shock or fire, do not expose the fixture to rain or moisture.

■ The housing must be replaced if they are visibly damaged.

■ Do not look directly at the LED light spot while the fixture is on.

WARNING!



WARNING! The *LMH 150W Spot* has a powerful pan motor. The torque reaction when the head is panned suddenly can cause the base to move if the fixture is standing unsecured on a surface. Do not apply power to the *LMH 150W Spot* unless the base is securely fastened to a surface or to rigging hardware.

WARNING! Use 2 clamps to rig the fixture. Do not hang the fixture from only one clamp. Lock each clamp with both 1/4-turn fasteners. Fasteners are locked only when turned a full 90° clockwise.

WARNING! When clamping the fixture to a truss or other structure at any other angle than with the yoke hanging vertically downwards, use two clamps of half-coupler type. Do not use any type of clamp that does not completely encircle the structure when fastened.



WARNING! Position or shade the head so that the front lens will not be exposed to sunlight or any other strong light source from any angle - even for a few seconds. See **Figure 2**. The *LMH 150W Spot* lens can focused the sun's rays, creating a potential fire hazard and causing damage.

IMPORTANT! Do not point strong light output from other fixtures at the *LMH 150W Spot*, as intense illumination can damaged the display.




Figure 2. Lenses can focused sunlight and strong light, presenting a risk of fire and damage to the fixture. Shield or shade the head if necessary.

3. PRODUCT INFORMATION

- Light Source: Ultra bright 150W LED
- PAN range: ?°
- TILT range: ?°
- Color wheel: 8 main colors + open with the rainbow
- Effects: 2 Gobos wheels: Fixed gobo wheel and rotating Gobo wheel. 7 Gobos + White with Bi-directional rotate effect,

4. INSTALLATION

The unit should be mounted via its screw holes on the bracket. Always ensure that the unit is firmly fixed to avoid vibration and slipping while operating. Always ensure that the structure to which you are attaching the unit is secure and is able to support a weight of 10 times of the unit's

5. CONNECTION

The device is equipped with the following interfaces:

1. DMX (in/out): XLR 3-pin socket
2. Power (in/out): powerCON socket


5.1 Connecting DMX signal

The connection is performed using cable with XLR-female -> XLR-Male plugs.

2 facet prism rotating, Frost filter. Gobo Indexing function. Adjustable flash frequency.

- 16 and DMX channel mode.
- 3-Pin XLR DMX input/output
- Power supply: 110 - 240V AC, 50-60Hz
- Power consumption: 200 W
- Net Weight: 12,4kg
- Dimensions: H(50)xW(40)xD(33) cm
- Dim. (case): H(66/54/)xW(90)xD(57,5) cm
- Weight (case): 78,2 kg

weight. Also always use a safety cable that can hold 12 times of the weight of the unit when installing the fixture. The equipment must be fixed by professionals. And it must be fixed at a place where is out of the touch of people and has no one pass by or under it.



CAUTION! At the last fixture, the DMX signal has to be terminated with a terminator. Solder a 120Ω resistor between signal (-) and signal (+) into a XLR plug and plug it in the DMX output of the last fixture.



5.2 Voltage specification

Input Voltage	Total Power	Frequency
100~240V	200W	50/60Hz

5.3 Connecting power supply

The connection is performed using power cable with PowerCon connector (included). The device must be operated by qualified personnel.

Make sure that the power grid supply parameters are consistent with device parameters and limitations are not exceeded.

CAUTION! In the case of cable damage do not attempt to repair. Replacement or repair can be made only on the manufacturer or by a person with appropriate permissions.



Using lamp, the change rate of power voltage should be within $\pm 10\%$, if the voltage is too high, it will shorten the light's life; if it's not enough, the lamp will be dark. Please restart it after turning off light for 20 minutes until full-cooling. Frequent switching will reduce the life span of lamps and bulbs; intermittent using will improve the life of bulbs and lamps.

6. DMX CHANNELS

16 CH Mode

CH	Function	Value	Description
1	Dimmer	0-255	From dark to bright
2	Strobe	0-10	No Strobe
		11-255	From Slow to Fast
3	Pan	0-255	Pan
4	Pan fine	0-255	Pan 16 bit
5	Tilt	0-255	Tilt
6	Tilt fine	0-255	Tilt 16 bit
7	Speed	0-255	Fast - Slow
8	Color	0-4	White
		5-9	White + Color 1
		10-14	Color 1
		15-19	Color 1 + Color 2
		20-24	Color 2
		25-29	Color 2 + Color 3
		30-34	Color 3
		35-39	Color 3 + Color 4
		40-44	Color 4
		45-49	Color 4 + Color 5
		50-54	Color 5
		55-59	Color 5 + Color 6
		60-64	Color 6
		65-69	Color 6 + Color 7
		70-74	Color 7
		75-79	Color 7 + Color 8
		80-84	Color 8
85-89	Color 8 + Color 9		
90-169	Color fast to slow in clockwise		
170-174	Stop		
175-255	Color slow to fast in anticlockwise		

CH	Function	Value	Description
9	Fixed gobo wheel	0-9	Open White
		10-19	Gobo 1
		20-29	Gobo 2
		30-39	Gobo 3
		40-49	Gobo 4
		50-59	Gobo 5
		60-69	Gobo 6
		70-79	Gobo 7
		80-89	White shaking
		90-99	Gobo 1 shaking
		100-109	Gobo 2 shaking
		110-119	Gobo 3 shaking
		120-129	Gobo 4 shaking
		130-139	Gobo 5 shaking
		140-149	Gobo 6 shaking
		150-159	Gobo 7 shaking
		10	Rotating Gobo wheel
10-19	Gobo 1		
20-29	Gobo 2		
30-39	Gobo 3		
40-49	Gobo 4		
50-59	Gobo 5		
60-69	Gobo 6		
70-79	Gobo 7		
80-89	White shaking		
90-99	Rotating Gobo 1 shaking		
100-109	Rotating Gobo 2 shaking		
160-204	Fast to slow in clockwise		
205-209	stop		
210-255	Slow to fast in anti clockwise		

CH	Function	Value	Description
		110-119	Rotating Gobo 3 shaking
		120-129	Rotating Gobo 4 shaking
		130-139	Rotating Gobo 5 shaking
		140-149	Rotating Gobo 6 shaking
		150-159	Rotating Gobo 7 shaking
		160-204	Fast to slow in clockwise
		205-209	STOP
		210-255	Slow to fast in anti clockwise
11	Gobo wheel rotating	0-127	Gobo angle
		128-190	Fast to Slow
		191-192	STOP
		193-255	Slow to Fast in anti clockwise
12	Zoom	0-255	Zoom
13	Prism and Frost	0-49	Invalid
		50-99	Prism 1
		100-149	Prism 2
		150-255	Frost
14	Prism rotating	0-127	Prism angle
		128-190	Fast to slow in clockwise
		191-192	STOP
		193-255	Slow to fast in anti clockwise
15	Macro	0-255	Brightness from dark to bright
		0-5	Invalid
		6-55	Demo 1
		56-105	Demo 2
		106-155	Demo 3
		156-205	Demo 4
		206-255	Random
16	Reset	0-25	No
		26-76	Small motor Reset

20 CH Mode

CH	Function	Value	Description
		77-127	XY Reset
		128-255	Whole RESET

OSTRZEŻENIE!



UWAGA! LMH 150W Spot posiada mocny silnik obrotu „pan”. Reakcja na moment obrotowy, gdy głowica zostanie nagle panoramowana, może spowodować ruch podstawy, jeśli urządzenie stoi niezabezpieczone na powierzchni. Nie należy włączać zasilania do głowicy, chyba że podstawa jest bezpiecznie przymocowana do powierzchni lub zabezpieczona linką bezpieczeństwa.


UWAGA! Użyj 2 zacisków (1/4-fastener), aby przymocować urządzenie. Nie zawieszaj urządzenia tylko na jednym zacisku. Zablokuj każdy zacisk za pomocą łączników 1/4 obrotu. Łączniki są blokowane tylko po obrocie o pełne 90° zgodnie z ruchem wskazówek zegara.

UWAGA! Podczas mocowania urządzenia do kratownicy lub innej konstrukcji pod innym kątem niż z jarzmem zwisającym pionowo w dół, należy użyć dwóch zacisków typu *Quick Half Coupler - (Hak)*. Nie używaj zacisków, które nie przylegają do konstrukcji po zamocowaniu.



UWAGA! Ustaw lub przyciemnij Głowice, aby przednia soczewka nie była narażona na działanie promieni słonecznych lub innych silnych źródeł światła pod dowolnym kątem - nawet przez kilka sekund. **Patrz rysunek 2.** Soczewka Głowicy może skupiać promienie słoneczne, tworząc potencjalne zagrożenie pożarowe i powodując uszkodzenia.

WAŻNE! Nie kieruj silnego strumienia świetlnego z innych urządzeń na Głowicę, ponieważ intensywne oświetlenie może uszkodzić wyświetlacz.



Rysunek 2. Soczewki mogą skupiać światło słoneczne i silne światło, stwarzając ryzyko pożaru i uszkodzenia urządzenia. W razie potrzeby należy osłonić lub zastonić głowę.

1. WPROWADZENIE

Dziękujemy za zakup urządzenia **LED MOVING HEAD 150W SPOT**. Ze względów bezpieczeństwa oraz w celu zapewnienia bezawaryjnej pracy urządzenia należy dokładnie zapoznać się z instrukcją.

2. ZASADY BEZPIECZENSTWA

■ Instalacja powinna być przeprowadzana przez wykwalifikowany personel, aby zminimalizować ryzyko przypadkowego porażenia prądem.

■ Przed instalacją urządzenia należy odłączyć urządzenie od sieci.

■ Przed podłączeniem urządzenia do sieci energetycznej należy sprawdzić, czy nie jest ono uszkodzone mechanicznie. Jeżeli widoczne są jakiegokolwiek ślady uszkodzenia należy niezwłocznie skontaktować się z dystrybutorem. Nie podłączać urządzenia do sieci elektrycznej.

■ Nie należy korzystać z urządzenia w warunkach dużej wilgotności powietrza oraz w temperaturze powyżej 40°C

■ Aby uniknąć uszkodzeń nie należy stosować rozpuszczalników organicznych do czyszczenia powłoki urządzenia.

■ Urządzenie należy instalować na stabilnych konstrukcjach.

■ Urządzenie powinno być zainstalowane w dobrze wentylowanym pomieszczeniu, w odległości co najmniej 15cm od najbliższej powierzchni (ściany, sufitu itp). Jednocześnie należy upewnić się, że otwory wentylacyjne nie są zatkane oraz wentylatory działają poprawnie.

3. INFORMACJE O PRODUKCIE

■ Źródło Światła: Ultra jasna LED 150W

■ PAN: 540°

■ TIL: 270°

■ Kolor: 8 kolorów + Open z tęczą

■ Efekty: 2 koła Gobo z rotacją i 7 zmiennymi wzorami, 2-ścienny pryzmat z rotacją, Frost filter

■ Ilość kanałów DMX: 16

■ 3-Pin XLR DMX input/output

■ Zasilanie: 110 - 240V AC, 50-60Hz

■ Pobór mocy: 200 W

■ Waga: 12,4 kg

■ Wymiary: W(50)xSz.(40)xGł.(33) cm

■ Wym. (case): W(66/54/)xSz.(90)xGł.(57,5) cm

■ Waga (case): 78,2 kg

4. INSTALACJA


Po wyjęciu urządzenia z opakowania należy sprawdzić czy nie zostało ono uszkodzone podczas transportu. Przed podłączeniem do sieci elektrycznej należy upewnić się, że urządzenie zamocowane jest stabilnie. Producent nie ponosi odpowiedzialności za uszkodzenia spowodowane niestabilnym zamocowaniem urządzenia.

Podczas korzystania z urządzenia należy zadbać o poprawne podłączenie go do sieci elektrycznej oraz prawidłowe uziemienie. Należy upewnić się, że parametry sieci elektrycznej są zgodne z wymaganiami urządzenia. Wszelkie czynności obejmujące obsługę w zakresie podłączania urządzenia do sieci elektrycznej powinny być wykonywane przez wykwalifikowany personel.

5. POŁĄCZENIA

Urządzenie wyposażone jest w następujące interfejsy:

1. DMX (wejście/wyjście) – złącza: XLR 3-pin
2. Zasilanie (wejście/wyjście) – złącze: powerCON



5.1 Podłączenie sygnału DMX

Połączenie odbywa się przy użyciu przewodu z wtyczkami XLR-Żeński -> XLR-Męski



5.2 Specyfikacja zasilania

Napięcie Zasilania	Pobór Mocy	Częstotliwość zasilania
100~240V	300W	50/60Hz

5.3 Podłączenie zasilania

Połączenie odbywa się przy użyciu przewodu zakończonego z jednej strony wtyczką sieci elektrycznej i wtyczką typu powerCON z drugiej strony (w zestawie). Urządzenie musi być obsługiwane przez

wykwalifikowany personel techniczny. Należy upewnić się, że parametry zasilania sieci energetycznej są zgodne z parametrami urządzenia i nie zostają przekroczone ograniczenia dotyczące poboru energii elektrycznej z sieci.



UWAGA! W przypadku uszkodzenia przewodu nie należy dokonywać samodzielnej naprawy. Wymiana lub naprawa może być wykonana jedynie w serwisie producenta lub przez osobę z odpowiednimi uprawnieniami.

6. LISTA KANAŁÓW DMX

16 CH Mode

CH	Function	Value	Description
1	Dimmer	0-255	From dark to bright
2	Strobe	0-10	No Strobe
		11-255	From Slow to Fast
3	Pan	0-255	Pan
4	Pan fine	0-255	Pan 16 bit
5	Tilt	0-255	Tilt
6	Tilt fine	0-255	Tilt 16 bit
7	Speed	0-255	Fast - Slow
8	Color	0-4	White
		5-9	White + Color 1
		10-14	Color 1
		15-19	Color 1 + Color 2
		20-24	Color 2
		25-29	Color 2 + Color 3
		30-34	Color 3
		35-39	Color 3 + Color 4
		40-44	Color 4
		45-49	Color 4 + Color 5
		50-54	Color 5
		55-59	Color 5 + Color 6
		60-64	Color 6
		65-69	Color 6 + Color 7
		70-74	Color 7
		75-79	Color 7 + Color 8
		80-84	Color 8
85-89	Color 8 + Color 9		
90-169	Color fast to slow in clockwise		
170-174	Stop		
175-255	Color slow to fast in anticlockwise		

CH	Function	Value	Description
9	Fixed gobo wheel	0-9	Open White
		10-19	Gobo 1
		20-29	Gobo 2
		30-39	Gobo 3
		40-49	Gobo 4
		50-59	Gobo 5
		60-69	Gobo 6
		70-79	Gobo 7
		80-89	White shaking
		90-99	Gobo 1 shaking
		100-109	Gobo 2 shaking
		110-119	Gobo 3 shaking
		120-129	Gobo 4 shaking
		130-139	Gobo 5 shaking
		140-149	Gobo 6 shaking
		150-159	Gobo 7 shaking
		160-204	Fast to slow in clockwise
205-209	stop		
210-255	Slow to fast in anti clockwise		
10	Rotating Gobo wheel	0-9	Open white
		10-19	Gobo 1
		20-29	Gobo 2
		30-39	Gobo 3
		40-49	Gobo 4
		50-59	Gobo 5
		60-69	Gobo 6
		70-79	Gobo 7
		80-89	White shaking
		90-99	Rotating Gobo 1 shaking
		100-109	Rotating Gobo 2 shaking

CH	Function	Value	Description
		110-119	Rotating Gobo 3 shaking
		120-129	Rotating Gobo 4 shaking
		130-139	Rotating Gobo 5 shaking
		140-149	Rotating Gobo 6 shaking
		150-159	Rotating Gobo 7 shaking
		160-204	Fast to slow in clockwise
		205-209	STOP
		210-255	Slow to fast in anti clockwise
11	Gobo wheel rotating	0-127	Gobo angle
		128-190	Fast to Slow
		191-192	STOP
		193-255	Slow to Fast in anti clockwise
12	Zoom	0-255	Zoom
13	Prism and Frost	0-49	Invalid
		50-99	Prism 1
		100-149	Prism 2
		150-255	Frost
14	Prism rotating	0-127	Prism angle
		128-190	Fast to slow in clockwise
		191-192	STOP
		193-255	Slow to fast in anti clockwise
15	Macro	0-255	Brightness from dark to bright
		0-5	Invalid
		6-55	Demo 1
		56-105	Demo 2
		106-155	Demo 3
		156-205	Demo 4
		206-255	Random
16	Reset	0-25	No
		26-76	Small motor Reset

CH	Function	Value	Description
		77-127	XY Reset
		128-255	Whole RESET



FLASH

F7100501

www.flash-butrym.pl